# USER MANUAL

## 【Projector Nano Go 7】

## 【Projector Nano Go 8】

DLP®
TEXAS INSTRUMENTS

**READ THIS USER MANUAL COMPLETELY BEFORE USAGE**

# 【Components of Projector Nano Go 7】



**1:** 3.5mm Earphone Jack / Audio Out

**2:** Standard USB Port 5V for Charging Output 500mA

**3:** DC 12V / 1.5A Power Input

**4:** HDMI Input Port

**5:** Power Switch

**6:** Touch Sensitive Key for Projector Mode (Movie or Document)

**7:** LED Battery Indicator

**8:** Touch Sensitive Key for Volume Control

**9:** Optical Lens

**10:** Focusing Wheel

# 【Components of Projector Nano Go 8】




**1:** 3.5mm Earphone Jack / Audio Out
**2:** Standard USB Port 5V for Charging Output 500mA
**3:** HDMI Input Port (supports also most devices with 5pin MHL to HDMI)
**4:** DC 12V / 1.5A Power Input
**5:** Reset Button
**6:** LED Indicator
**7:** Power Switch
**8:** Projector Mode (Standard or Presentation)
**9:** Volume Down
**10:** Volume Up
**11:** Focusing Wheel
**12:** Optical Lens

# 【Specification Projector Nano Go 7 / Nano Go 8】

- Texas Instruments DLP Technology
- Megabright LED lamp: 85 Lumen
- LED Lamp: 20,000 hours lifetime
- Up to 100” screen size
- HDMI video/audio input
- Compatible with HDMI for:
  iPad 1st,2nd, 3d and 4th generation*, iPad mini*, iPhone 4⁄4S and 5*, iPod 4th and 5th generation* (**Apple devices require an Apple Digital A/V adapter (not included) for HDMI use.**
  Most smartphones and tablets
  Cameras and Camcorders with HDMI port
  Mac & PC notebooks with HDMI port
- 1080p HD video input supported
- 854 x 480 WVGA 16:9 resolution
- Contrast ratio 1000:1
- 100% offset
- Long focus lens
- Manual focus
- Stereo speaker with digital control
- Analogue audio output: 3.5mm jack
- Rechargeable 3800mAh battery
- Up to 2 hours projection time
- USB powerbank for smartphone (5V / 500mA)
- AC/DC charger with Europe, UK and USA plug included ( (12V / 1.5A)
- Tripod included
- HDMI-HDMI cable included
- Nano Go 7: dimension 99.5W x 22.5H x 99D(mm) Weight: 220gram
- Nano Go 8: dimension 100W x 20.0H x 100D(mm) Weight: 220gram

# 【Extra Specification only for Nano Go 8】

- Supports 5pin MHL-video/audio input via the HDMI input port
- MHL-HDMI cable included (supports most devices with 5pin MHL)
- An 11pin MHL-HDMI adapter (not included) may be required for 11pin MHL devices

# 【Instruction Manual Nano Go 7 and Nano Go 8】

- This product supports the DC12V adapter power supply. It can be operated while its battery is being charged. Fully charge the battery before first use (approximately 3 to 5 hours) once fully charged, the battery projection time is around 2 hours. It is recommended to supply the projector with DC12V adapter, which is good to save battery life.
- The standard USB connector is able to provide external devices (such as mobile phones) with charging service up to 5V/500mA.
- For manual focus, tune the focusing wheel in slow and light way until the focusing wheel turn to maximum it will stop. At that time, please do not tune it anymore.
- Connect AC adapter with projector for charging, the LED indicator light will illuminate red to indicate the projector is currently charging and then revert to green when the projector is fully charged.
- When the battery icon on projection screen shows low battery, please connect the AC adapter with projector to make sure projector performs work continuously. When turn on the projector but found it doesn't work, probably the battery power is not enough.
- The Projector can display media just about anywhere! However, for the best quality, we suggest you find a light colored wall (preferably smooth and white) and place the Projector with its lens facing the location. The Projector can show media up to 100", just move the projector towards and away from the wall to adjust the size of the picture. Dimming room lights will also add to viewing quality.
- For most devices the projector can also display your device screen on the wall (mirroring)

# 【Instruction Manual Nano Go 7】

- This product supports the HDMI signal input only, other forms of signal cannot be inputted until being transformed into the HDMI signal.
- The touch-sensitive key's supports the functions of mode switch and volume control. This product has two running modes which are presentation and standard. To switch modes, long press the "M" key. For volume control, touch the "+" or "-" touch-sensitive key on top of the projector and adjust the volume..

# 【Instruction Manual Nano Go 8】

- This product supports the HDMI and MHL signal input, other forms of signal cannot be inputted until being transformed into the HDMI or MHL signal.
- This product has two running modes which are Movie and Document. To switch modes, press the "Mode" key. For volume control, you can adjust the volume by pressing the buttons "+" or "-" on the left side.

# 【Instructions for safety and use】
# This product contains a rechargeable battery

**1:** This product cannot be close to or contact with fire directly, for the build-in battery may explode at high temperature.

**2:** This product cannot be exposed to humid environments or contact with water directly. Otherwise, it may be damaged or even cause explosion.

**3:** Serious smoke and dust may affect the performance of the product or damage its components, such as lens or fans.

**4:** Dangers for humans: This product is not suitable to be touched by children, product itself or the strong LED light from lens may cause

damages to children, especially their eyes.

**5:** This product is made of plastic shell with no resistance to pressure. Please do not place heavy things on it.

**6:** Environment requests: The usage of this product under damp, extremely high and low-temperature and temperature fluctuation conditions will reduce its service life.

**7:** Only qualified persons may perform technical work on the product. The product may not be opened or changed if there is any fault. Please contact with your local dealers to provide official maintenance service.

**8:** When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully

**9:** Before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

**10:** Read these instructions – All the safety and operating instructions should be read before the appliance is operated.

**11:** Keep these instructions – The safety and operating instructions should be kept for future reference.

**12:** Heed all warnings – All warnings on the appliance and in the operating instructions should be adhered to.

**13:** Follow all instructions – All operation and use instructions should be followed.

**14:** Do not use this apparatus near water – The appliance should not be used near water; for example, near a bath tub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.

**15:** Clean only with dry cloth – The appliance should be cleaned only as recommended by the manufacturer.

**16:** Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.

**17:** Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

**18:** Only use attachments / accessories specified by the manufacturer.

**19:** Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

**20:** This appliance shall not be exposed to dripping or splashing water and that no object filled with liquids such as vases shall be placed on the apparatus.

**21:** Power Sources – The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance. Do not overload wall outlet.

**22:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type. There is a high energy rechargeable battery inside the projector, do not throw it into fire to avoid danger of explosion.

**23:** Do not charge the internal rechargeable battery longer than specified to prevent danger of fire. Overcharging rechargeable batteries may shorten their life span.

**24:** Do not attempt to dismantle, open or repair this product yourself. If a fault occurs, seek advice from your local qualified service technician or contact the distributor.

## 【Important notes】

Avoid installing the unit in locations described below:

**1:** Places exposed to direct sunlight or close to heat radiating appliances such as electric heaters.

**2:** Places subject to constant vibration.

**3:** Dusty, Humid or moist places

**NOTE:** This product is not magnetically shielded and may cause color distortion on the screen of some TVs or video monitors. To avoid this you may need to move the unit further away from the TV or monitor if unnatural color shifts or image distortion occurs.

# 【Trademark】

HDMI, HDMI High-Definition Multimedia interface, and the HDMI logo are trademarks of HDMI Licensing LLC, registered in the U.S. and other countries.

iPad, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

DLP and the DLP ® logo are trademarks of Texas Instruments.

## 【RISK GROUP 2】

**CAUTION: POSSIBLE HAZARDOUS OPTICAL RADIATION EMITTED FROM THIS PRODUCT. DO NOT STARE AT OPERATING LAMP. MAYBE HARMFUL TO THE EYES.**